



### Belt-pack Intercom Integration



**Beltpack Intercom 4-pin XLR**



PIN	FUNCTION			
	603	623	603R	623R
1	Mic (L)	Mic (L)	Mic (L)	Mic (L)
2	Mic (H)	Mic (H)	Mic (H)	Mic (H)
3	Headphone (L)	Headphone common	Headphone (L)	Headphone common
4	Headphone (H)	Ch. B headphone (H)	Headphone (H)	Ch. B headphone (H)
5		Ch. A headphone (H)		Ch. A headphone (H)
6		Headphone common		